

# VOR or TACAN RWY 14


FORT WAYNE INTL (FWA)

VORTAC FWA <b>117.8</b> Chan <b>125</b>	APP CRS <b>139°</b>	Rwy Idg TDZE Apt Elev	<b>8001</b> <b>802</b> <b>814</b>
---	------------------------	-----------------------------	---

**ASR** DME or RADAR Required.



MISSED APPROACH: Climb to 3000 via FWA R-128 to OSBER INT/FWA 22 DME and hold.

ATIS <b>121.25 349.0</b>	FORT WAYNE APP CON <b>127.2 284.6</b>	FORT WAYNE TOWER <b>119.1 272.725</b>	GND CON <b>121.9 348.6</b>	CLNC DEL <b>124.75</b>
-----------------------------	--	--	-------------------------------	---------------------------



EC-2, 22 OCT 2009 to 19 NOV 2009

EC-2, 22 OCT 2009 to 19 NOV 2009



CATEGORY	A	B	C	D	E
S-14	1280-1	478 (500-1)	1280-1¼ 478 (500-1¼)	1280-1½ 478 (500-1½)	1280-1¾ 478 (500-1¾)
CIRCLING	1300-1	486 (500-1)	1300-1½ 486 (500-1½)	1380-2 566 (600-2)	1520-2½ 706 (800-2½)