

MIAMI NINE DEPARTURE



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RUNWAYS 27L and 27R: Climb on runway heading or as assigned.

NOTE: If assigned other than runway heading climb on runway heading to 1100 before turning to assigned heading.

Maintain 2000 feet or assigned higher altitude and expect vectors to appropriate transition. Expect further clearance to filed altitude ten (10) minutes after departure.

BEECH TRANSITION (MIA9.BEECH): From over FLL VOR/DME via FLL R-098 to BEECH INT. Thence as filed.

EONNS TRANSITION (MIA9.EONNS): Intercept the DHP VORTAC R-151 to EONNS INT. Thence as filed.

HEDLY TRANSITION (MIA9.HEDLY): From over DRUUM DME FIX via PHK R-157 to HEDLY INT. Thence as filed.

MNATE TRANSITION (MIA9.MNATE): Intercept the DHP VORTAC R-195 to MNATE DME FIX. Thence as filed.

PADUS TRANSITION (MIA9.PADUS): From over VKZ VOR/DME via VKZ R-058 to JANUS INT and ZFP R-245 to PADUS DME FIX. Thence as filed.

SKIPS TRANSITION (MIA9.SKIPS): From over VKZ VOR/DME via VKZ R-108 to SKIPS INT. Thence as filed.

VALLY TRANSITION (MIA9.VALLY): From over VKZ VOR/DME via VKZ R-058 to VALLY DME FIX. Thence as filed.

WINCO TRANSITION (MIA9.WINCO): From over DHP VORTAC via DHP R-322 to WINCO INT. Thence as filed.

SE-3, 22 OCT 2009 to 19 NOV 2009

SE-3, 22 OCT 2009 to 19 NOV 2009