



DEPARTURE ROUTE DESCRIPTION

JETS

Jets requesting 17,000 and below expect GARLAND Departure.

TAKE-OFF RUNWAY 17: Climbing right turn via heading 200° and TTT VOR/DME R-180 to NAHMU/TTT VOR/DME 20 DME, expect radar vectors to appropriate route. Maintain 2000 feet and expect filed altitude 10 minutes after departure.

TAKE-OFF RUNWAY 35: NA.

BELCHER TRANSITION (DALL8.EIC): (For aircraft inbound to the JAN, MLU, and SHV terminal areas only.) From over TTT VOR/DME via TTT R-094 to POTEN INT, then via EIC R-259 to EIC VORTAC.

EL DORADO TRANSITION (DALL8.ELD): (For aircraft inbound to Memphis Terminal area. Aircraft should file and/or expect appropriate STAR.) From over TTT VOR/DME via TTT R-084 to SOLD0 INT, then via UIM R-261 to UIM VOR/DME, then via UIM R-072 and ELD R-254 to ELD VORTAC.

LITTLE ROCK TRANSITION (DALL8.LIT): From over TTT VOR/DME via TTT R-064 to ORTRO INT, then via LIT R-235 to LIT VORTAC.

MERIDIAN TRANSITION (DALL8.MEI): (For aircraft inbound to the Atlanta Terminal area.) From over TTT VOR/DME via TTT R-084 to SOLD0 INT, then via UIM R-261 to UIM VOR/DME, then via UIM R-072 and ELD R-254 to ELD VORTAC, then via ELD R-097 and MEI R-281 to MEI VORTAC.

QUITMAN TRANSITION (DALL8.UIM): (For aircraft inbound to Shreveport Terminal area.) From over TTT VOR/DME via TTT R-084 to SOLD0 INT, then via UIM R-261 to UIM VOR/DME.

SAWMILL TRANSITION (DALL8.SWB): From over TTT VOR/DME via TTT R-094 to POTEN INT, then via EIC R-259 to TEKBE INT, then via SWB R-291 to SWB VOR/DME.

SIDON TRANSITION (DALL8.SQS): From over TTT VOR/DME via TTT R-084 to SOLD0 INT, then via UIM R-261 to UIM VOR/DME, then via UIM R-072 and ELD R-254 to ELD VORTAC, then via ELD R-077 and SQS R-262 to SQS VORTAC.

SOLD0 TRANSITION (DALL8.SOLD0): From over TTT VOR/DME via TTT R-084 to SOLD0 INT.

TEXARKANA TRANSITION (DALL8.TXK): From over TTT VOR/DME via TTT R-074 to SHERO INT, then via TXK R-244 to TXK VORTAC.

SC-2, 22 OCT 2009 to 19 NOV 2009

SC-2, 22 OCT 2009 to 19 NOV 2009