BARET FOUR ARRIVAL

(BARET.BARET4) 09183

SAN DIEGO, CALIFORNIA

SOCAL APP CON
124.35 279.625
LINDBERGH ATIS
134.8
NORTH ISLAND ATIS ★
317.8

NOTE: RADAR and DME required on TNP, EED, and PKE transitions.

NOTE: When SAN arrivals are using Rwy 9, aircraft can expect to depart and re-enter the TCA southwest of PGY VORTAC.

TURBOJET VERTICAL NAVIGATION PLANNING INFORMATION

TNP, EED and PKE transitions expect to cross Saltn Int at or below FL 240, expect to cross 25 NM northeast of the PGY VORTAC at 12000.

TWENTYNINE PALMS
114.2 TNP
Chan 89
N34°06.73′ - W115°46.19′
L-4, H-4

NEEDLES
115.2 EED
Chan 99
N34°45.96′
W114°28.45′
L-7, H-4

THERMAL
116.2 TRM
Chan 109

OCEANSIDE
115.3 OCN
Chan 100

JULIAN
114.0 JLI
Chan 87

MISSION BAY
117.8 MZB
Chan 125

LOCALIZER 111.55
I-SAN
Chan 52 (Y)

LOCALIZER 110.9
I-UBR
Chan 46

SHADI
N33°37.24′
W115°45.70′

PARKER
117.9 PKE
Chan 126
N34°06.12′
W114°40.93′
L-4-5, H-4

KARRO
N33°15.89′
W116°22.46′

MOMAR
N33°30.90′
W115°56.67′

SALTN
N33°22.75′
W116°10.70′

(IFEHI)
N32°48.08′
W116°37.80′

KUMBA
N32°45.72′
W116°03.22′

SARGS
N32°46.90′
W117°23.37′

BARET
N32°46.45′
W116°40.65′

SWATT
N32°40.75′
W116°57.97′

PILLO
N32°46.22′ - W116°28.12′

TURBOJET VERTICAL NAVIGATION PLANNING INFORMATION
Expect to cross at 10000′.

SAN DIEGO INTL

NORTH ISLAND NAS
(HALSEY FIELD)

(IFSOX)
N32°41.70′
W117°23.03′

(IFHEJ)
N32°39.60′
W116°53.31′

POGGI
109.8 PGY
Chan 35
N32°36.62′ - W116°58.75′

IMPERIAL
115.9 IPL
Chan 106
N32°44.93′ - W115°30.51′
L-4, H-4

(NARRATIVE ON FOLLOWING PAGE)

NOTE: Chart not to scale.

ST-373 (FAA)