# ANAHEIM THREE DEPARTURE

(ANAHM3.SLI) 09015

SANTA ANA/JOHN WAYNE ARPT-ORANGE COUNTY (SNA)

SANTA ANA, CALIFORNIA

SL-377 (FAA)

ATIS 126.0
CLNC DEL 118.0
GND CON
(EAST) 120.8
(WEST) 132.25
SOCAL DEP CON
124.65 281.4

TAKE-OFF MINIMUMS:
Rwys 1L/R, 19L/R: standard

NOTE: All Rwys, cross DER at or above 35′ AGL.

NOTE: This departure procedure not authorized for Turbo-prop or Turbo-jet aircraft.

NOTE: RADAR required.

LAKE HUGHES
108.4 LHS
Chan 21
N34°40.98′ - W118°34.62′
L-3-4-7

VAN NUYS
113.1 VNY
Chan 78

PALMDALE
114.5 PMD
Chan 92

VICTORVILLE
109.4 VCV
Chan 31

APLES
N34° 32.91′
W117° 08.97′
10000

113.2 DAG
Chan 79

HECTOR
112.7 HEC
Chan 74
N34°47.82′
W116°27.78′
L-7, H-4

DARTS
N34°09.36′
W118°16.18′

POMONA
110.4 POM
Chan 41

LOS ANGELES
113.6 LAX
Chan 83
N33°55.99′
W118°25.92′

BAYJY
N34°00.44′
W117°47.14′

SADDE
N34° 02.34′
W118° 45.88′

POXKU
N33°51.22′
W117°46.94′

PARADISE
112.2 PDZ
Chan 59
N33°55.10′ - W117°31.80′

VENTURA
108.2 VTU
Chan 19
N34°06.90′ - W119°02.97′
L-3-4-7, H-4

WILMA
N33°46.28′
W118°15.57′

SEAL BEACH
115.7 SLI
Chan 104
N33°47.00′ - W118°03.29′

112.5 FIM
Chan 72

†Hector Transition
††Lake Hughes Transition
**Ventura Transition

NOTE: Chart not to scale.

(NARRATIVE ON FOLLOWING PAGE)