


 DEPARTURE ROUTE DESCRIPTION

TAKEOFF RWY 6: Climb to 3000 via heading 060°, at PXT VORTAC 3 DME turn left direct PXT, thence. . .

TAKE-OFF RWY 14: Climbing right turn to 3000 via heading 250° within PXT 2.5 DME, intercept PXT R-223, thence. . .

TAKE-OFF RWY 24: Climbing left turn to 3000 via heading 210°, intercept PXT R-223, thence. . .

TAKE-OFF RWY 32: Climbing left turn to 3000 via heading 180°, intercept PXT R-223, thence. . .

Via R-223 to JUMIX, PXT R-223/13 DME, then arc CCW SW of PXT via 13 mile arc to ZIRAT, PXT R-203/13 DME, then via PXT R-203 to SWABY, PXT R-203/25 DME, then via assigned transition or expect radar vectors to join assigned route. Cross ZIRAT at or below 7000.

CASANOVA TRANSITION (SWABY6.CSN): Via CSN VORTAC R-131 to CSN.

EDDYS TRANSITION (SWABY6.EDDYS): Via PXT R-203 to UCINE, then via OTT R-184 to EDDYS. Cross SWABY at or above 15,000.

GORDONSVILLE TRANSITION (SWABY6.GVE): Via GVE VORTAC R-101 to GVE.

HARCUM TRANSITION (SWABY6.HCM): Via HCM VORTAC R-026 to HCM.

HOPEWELL TRANSITION (SWABY6.HPW): Via HPW VORTAC R-047 to HPW.

STEIN TRANSITION (SWABY6.STEIN): Via PXT R-203 to UNNAC, then via CCV VORTAC R-323 to STEIN.