



DEPARTURE ROUTE DESCRIPTION

Fly assigned heading and altitude for radar vectors to assigned transition. Expect filed altitude 10 minutes after departure.

LOST COMMUNICATIONS: If no transmissions are received within one minute after departure, maintain assigned heading until 7000 feet, then climb to filed altitude via direct DEN VOR/DME, thence via assigned transition. If filed altitude is above 10000 feet, cross DEN VOR/DME at or above 11000 feet.

BLUE MESA (HI) TRANSITION (ROCKI7.HBU): From over DEN VOR/DME via DEN R-240 and HBU R-021 to HBU VOR/DME.

DOVE CREEK (HI) TRANSITION (ROCKI7.DVC): From over DEN VOR/DME via DEN R-240 and MTJ R-039 to MTJ VOR/DME, then via MTJ R-218 and DVC R-035 to DVC VORTAC.

KREMMLING TRANSITION (ROCKI7.RLG): From over DEN VOR/DME via DEN R-275 and RLG R-073 to RLG VOR/DME.

MEEKER TRANSITION (ROCKI7.EKR): From over DEN VOR/DME via DEN R-275 and RLG R-073 to RLG VOR/DME, then via RLG R-260 and EKR R-078 to EKR VOR/DME.

MONTROSE TRANSITION (ROCKI7.MTJ): From over DEN VOR/DME via DEN R-240 and MTJ R-039 to MTJ VOR/DME.

RED TABLE TRANSITION (ROCKI7.DBL): From over DEN VOR/DME via DEN R-251 and DBL R-062 to DBL VOR/DME.

SW-1, 22 OCT 2009 to 19 NOV 2009

SW-1, 22 OCT 2009 to 19 NOV 2009