

CARDS SEVEN DEPARTURE



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 5: Climb and maintain 2500 feet, expect vectors to appropriate route, expect filed altitude 10 minutes after departure.

TAKE-OFF RWYS 12L, 12R: Climb via heading 122° to 1000 before turning left, then climb and maintain 2500 feet, expect vectors to appropriate route, expect filed altitude 10 minutes after departure.

TAKE-OFF RWY 23: Climb via heading 227° to 2000 before turning right, then climb and maintain 2500 feet, expect vectors to appropriate route, expect filed altitude 10 minutes after departure.

TAKE-OFF RWYS 30L, 30R: Climb via heading 302° to 1700 before turning, then climb and maintain 2500 feet, expect vectors to appropriate route, expect filed altitude 10 minutes after departure.

BRADFORD TRANSITION (CARDS7.BDF): From over CSX VOR/DME via CSX R-010 to SKUTR INT, then via BDF R-198 to BDF VORTAC.

LEBOY TRANSITION (CARDS7.LEBOY): From over CSX VOR/DME via CSX R-346 to LEBOY INT.

NEENS TRANSITION (CARDS7.NEENS): From over CSX VOR/DME via CSX R-355 to NEENS INT.

SPINNER TRANSITION (CARDS7.SPI): From over CSX VOR/DME via CSX R-026 to TEWHY INT, then via SPI R-207 to SPI VORTAC.

EC-3, 22 OCT 2009 to 19 NOV 2009

EC-3, 22 OCT 2009 to 19 NOV 2009