



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RUNWAY 3: Turn left heading 025°, expect radar vectors to assigned airway/route. Thence....

TAKE-OFF RUNWAY 7: Turn right heading 120°, expect radar vectors to assigned airway/route. Thence....

TAKE-OFF RUNWAY 21: Turn left heading 205°, expect radar vectors to assigned airway/route. Thence....

TAKE-OFF RUNWAY 25: Turn left heading 205°, expect radar vectors to assigned airway/route. Thence....

....maintain 12000' or assigned lower altitude, expect filed altitude/flight level 10 minutes after departure.

LOST COMMUNICATIONS: Climb direct GEG VORTAC before proceeding on course. Cross GEG VORTAC at or above: NE-bound V120-448 3900'; E-bound V2 4200'. Aircraft departing RWY 3, if not in contact with ATC within 10 NM after takeoff, turn left direct GEG VORTAC, cross GEG VORTAC at or above 4200', thence via assigned fix/route.

NW-1, 22 OCT 2009 to 19 NOV 2009

NW-1, 22 OCT 2009 to 19 NOV 2009