



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RUNWAY 17: Climbing right turn via heading 200° and TTT R-180 to NAHMU/TTT VOR/DME 20 DME, expect radar vectors to appropriate route. Maintain 2000 feet and expect filed altitude 10 minutes after departure.

TAKE-OFF RUNWAY 35: NA

ARDMORE TRANSITION (TEX9.ADM): From over FUZ VORTAC via FUZ R-348 to LOWGN INT, then via ADM R-179 to ADM VORTAC.

BLECO TRANSITION (TEX9.BLECO): (ATC assigned.) From over FUZ VORTAC via FUZ R-360 to BLECO INT.

EAKER TRANSITION (TEX9.EAKER): (For aircraft inbound to the Tulsa terminal area.) From over FUZ VORTAC via FUZ R-012 to EAKER INT.

GRABE TRANSITION (TEX9.GRABE): (ATC assigned.) From over FUZ VORTAC via FUZ R-012 to GRABE INT.

MCALESTER TRANSITION (TEX9.MLC): (For all aircraft overflying the MLC VORTAC or intercepting J105.) From over FUZ VORTAC via FUZ R-022 to TIKYS INT, then via MLC R-206 to MLC VORTAC.

OKMULGEE TRANSITION (TEX9.OKM): (For all aircraft overflying OKM VOR/DME proceeding via J181 to BDF to destinations in the Chicago terminal area and north.) From over FUZ VORTAC via FUZ R-012 to EAKER INT, then via OKM R-196 to OKM VOR/DME.

ROLLS TRANSITION (TEX9.ROLLS): (For all aircraft proceeding northwestbound via J52.) From over FUZ VORTAC via FUZ R-348 to LOWGN INT, then via ADM R-179 to ADM VORTAC, then via ADM R-303 to ROLLS INT.

TULSA TRANSITION (TEX9.TUL): (For all aircraft overflying TUL VORTAC.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT, then via TUL R-201 to TUL VORTAC.

WILL ROGERS TRANSITION (TEX9.IRW): (For all aircraft inbound to the Oklahoma City area or overflying IRW VORTAC.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT, then via IRW R-145 to IRW VORTAC.

ZEMMA TRANSITION (TEX9.ZEMMA): (ATC assigned.) From over FUZ VORTAC via FUZ R-360 to ZEMMA INT.

SC-2, 22 OCT 2009 to 19 NOV 2009

SC-2, 22 OCT 2009 to 19 NOV 2009