


APP CRS 175°	Rwy Idg TDZE Apt Elev	3511 598 598
------------------------	-----------------------------	---


▲ NA	Use Fort Smith altimeter setting.	MISSED APPROACH: Climb to 3300 direct ELKVI WP and hold.
-------------	-----------------------------------	--

AWOS-3 118.575	FORT WORTH CENTER 132.2 338.35	CTAF 122.9
--------------------------	--	----------------------




SC-1, 22 OCT 2009 to 19 NOV 2009

SC-1, 22 OCT 2009 to 19 NOV 2009



3300	ELKVI	One Minute Holding Pattern
↑	✦	
RW17	AGNUC	EBUJE
2400	355°	175°
3000	355°	175°
5 NM	5 NM	



CATEGORY	A	B	C	D
FORT SMITH ALTIMETER SETTING MINIMUMS				
S-17	1360-1 762 (800-1)	1360-1¼ 762 (800-1¼)		NA
CIRCLING	1360-1 762 (800-1)	1360-1¼ 762 (800-1¼)		NA

LIRL Rwy 17-35